



ELECTROCOMPANIET

If music *really* matters™



EMS 1

Music Streamer

Owner's Manual

EN

N

e

About the EMS 1 Electrocompaniet Music Streamer

This unit is designed to work with the Electrocompaniet PD 1 DAC only. A radio link is established between your computer and the PD 1. This link is used to transmit music from the USB-port of your computer to the PD 1.

Unpacking the EMS 1

Immediately upon receipt of the EMS 1, inspect the carton for possible damages during transport.

The contents of the carton

- 1 pc. Electrocompaniet EMS1
- 1 pc. USB type 2 cable.
- 2 pcs. antennas.
- 4 pc. rubber pads.

How to set up the EMS 1

1. Antennas

Screw one antenna to the antenna port on the EMS 1, tighten it with your fingertips, no tool is necessary. Screw the other antenna to the antenna port on the back-panel of the PD 1, labelled RF. Both antennas should be set in an upright position and the top point should be kept away from any close-by metallic objects.

2. USB type 2 cable

Connect the USB type 2 cable to the USB-port on the EMS 1 and to the USB-port on your computer.

Verify that the units are set to the same channel

Both the PD 1 and the EMS 1 must be set to the same channel. From the factory all units are set to channel 0. If you need to change the channel this can be done by turning the channel indicators on both units, labelled Ch. A small screwdriver can be used.

Set-up

Once connected and on the same channel the units will connect automatically. The volume will automatically be set to the preset level. If a connection is not established, or the connection is lost, the volume will automatically be set to 0.

The EMS 1 will replace the sound card on your computer. To use EMS 1 you must change the sound settings to make EMS 1 the preferred sound output. You might need to restart your media player after setting up the EMS 1.



If service is needed

Your dealer will have all relevant information regarding the service centre in your area and will ensure that your unit is serviced with minimum delay. If there is no service facility available in your country, please ship the unit to the following address:

ELECTROCOMPANIET AS
BREIVIKVEIEN 7
4120 TAU
NORWAY
Switchboard: +47 51 74 10 33
Fax: +47 51 74 10 10
Service: +47 51 74 10 23
E-mail: service@electrocompaniet.no
www.electrocompaniet.no
Service department: service@electrocompaniet.no

The end-user is responsible for all shipping charges, insurance, and re-importation and duty charges. When shipping a product to the factory for service, always include the following:

1. A sales slip or other proof of purchase if repair is claimed under warranty.
2. A proforma invoice with value of goods, stating that the product is being returned to Norway for repair.
3. An accompanying letter describing faults, symptoms, or problems with the unit.
4. Always ship the unit in its original carton and packaging material to prevent damage in transit. Electrocompaniet will not cover damages incurred in transit.

If you require further information concerning the operation of the unit or if you have any questions related to service, please do not hesitate to contact your dealer or national distributor.

Om EMS 1 Electrocompaniet Music Streamer

Denne enheten er laget for kun å brukes sammen med Electrocompaniet PD 1 DAC. Den etablerer en radiolink mellom din datamaskin og PD 1 og ved hjelp av denne overføres musikk fra USB-porten på din datamaskin til PD 1.

Pakke ut EMS 1

Etter du har mottatt EMS 1 bør du inspisere esken for skader som kan ha oppstått under transport.

Eskens innhold

- 1 stk Electrocompaniet EMS 1
- 1 stk USB type 2 kabel
- 2 stk antenner
- 4 stk gummiføtter

Hvordan koble EMS 1 til PD 1

Tilkoblinger

1. Antenner

Skru en antenne til antenne porten på EMS 1, bruk kun fingrene til å stramme, det er ikke nødvendig å bruke noe verktøy. Skru den andre antennen til antenneporten på baksiden av PD 1, merket RF. Sørg for at antennene står rett opp og at toppen av antennene står mest mulig fritt og ikke nær metalliske objekter.

2. USB type 2 kabel

Denne kobles mellom USB-porten på EMS 1 og en USB-port på din datamaskin.

Sjekk at begge enhetene er innstilt på samme kanal

Både PD 1 og EMS 1 må være innstilt til samme kanal. Fra fabrikken er begge satt til kanal 0. Dersom du har behov for å endre kanal kan dette gjøres ved å skru på kanalindikatorerne på PD 1 og EMS 1, disse er merket Ch. Et lite skrujern kan benyttes til dette.

Oppstart

Radiokommunikasjonen mellom PD 1 og EMS 1 etableres automatisk straks begge enhetene er koblet til og de er på same kanal. Volumet justeres da automatisk til det tidligere valgte nivået. Dersom det ikke etableres kontakt, eller forbindelsen brytes, vil volumet automatisk settes til 0.

EMS 1 erstatter lydkortet på din datamaskin. For å bruke EMS 1 må den velges som lydenhet i lydoppsettet på din datamaskin. Det kan være nødvendig å restarte media spilleren etter installasjon av EMS 1.

Dersom service er nødvendig

Din forhandler vil ha all relevant informasjon om service på ditt Electrocompaniet produkt og ved behov for service skal din forhandler kontaktes.

Når du sender inn et produkt til service, husk alltid å sende med:

- Kvittering eller annet bevis på når produktet ble kjøpt om reparasjon skal skje på garanti.
- Proformafaktura med verdien på produktet som viser at produktet skal returneres til Norge for reparasjon. (Gjelder ikke apparater som sendes i Norge.)
- Feilbeskrivelse som forklarer feilsymptomer, problemer og hvordan det har oppstått.
- Send produktet i original innpakning for å forhindre skader under transport. Electrocompaniet kan ikke dekke skader som har oppstått under transport.

Sluttbruker er ansvarlig for alle fraktkostnader, forsikring, re-importering og tollkostnader.

Ønsker du mer informasjon om produktet eller har spørsmål angående service se vår hjemmeside for kontaktinformasjon.

Electrocompaniet as
Breivikveien 7
N-4120 Tau
Norway
www.electrocompaniet.com
Service avdeling: service@electrocompaniet.no

e



LOCAL DEALER

Warning!

To avoid risk of fire or electric shock, do not expose this appliance to rain or moisture.

Verify line voltage before use.

Do not remove cover. No user serviceable parts inside.

Refer servicing to qualified service personnel.

The warranty is void if the product is tampered with by non-authorized personnel.

Use only authorized Electrocompaniet service center.

Made in Norway
www.electrocompaniet.no